




JOHN DEERE - 6M STAGE IV*

STANDARD 6110M



MX equipment : T412 on 6110M



 T408 - T410 - T412 - U307 - U308 - U309 - U310 - U312 - U407 - U408 - U408P - U409 - A110 - U410 - U410P - U412 -

 R28 - R38

 e-Pilot - Original control valve - ECOPILOT - PROPILOT - FLEXPILLOT

MXCONFIG



*Equipped models of this range : **STANDARD 6110M / 6120M / 6130M / 6135M / 6145M / 6155M / 6175M / 6195M**

Check the recommendations and configure all MX equipments to your tractor with the application **MXConfig**.

MX solution for JOHN DEERE

