




# JOHN DEERE - 6M STAGE IV\*

## STANDARD 6135M



MX equipment : U414 on 6135M



 T410 - T412 - T417 - U309 - U310 - U312 -  
T414 - U409 - A110 - U410 - U410P -  
U412 - U412P - U414 - T410P - T412P

 R28 - R38

 e-Pilot - Original control valve - ECOPILOT - PROPILOT - FLEXPILLOT

### MXCONFIG



\*Equipped models of this range : **STANDARD 6110M / 6120M / 6130M / 6135M / 6145M / 6155M / 6175M / 6195M**

Check the recommendations and configure all MX equipments to your tractor with the application **MXConfig**.

## MX solution for JOHN DEERE

