



**LS - J\***

**HST J23**



MX equipment : CI on J23



**CI**



**Direct Control**



**MXCONFIG**



\*Equipped models of this range : **HST J23 / J27**

Check the recommendations and configure all MX equipments to your tractor with the application **MXConfig**.

**MX solution for LS**