



# LS - R SERIES\*

## STANDARD R50



MX equipment : C4 on R50



30C - C4 - C4+



R05



Original control valve - Cable Control

### MXCONFIG



\*Equipped models of this range : **STANDARD R41 / R50.**

Check the recommendations and configure all MX equipments to your tractor with the application **MXConfig**.

MX solution for LS